

LEGEND			
[Symbol]	= RANGE	[Symbol]	= TANKLESS WATER HEATER
[Symbol]	= LOW CASEWORK	[Symbol]	= REF
[Symbol]	= UPPER CASEWORK	[Symbol]	= OVEN
[Symbol]	= FULL HEIGHT CASEWORK	[Symbol]	= DISH WASHER
[Symbol]	= WASHER/DRYER COMBO	[Symbol]	= TRASH COMPACTOR
[Symbol]	= WASHER	[Symbol]	= FURNACE
[Symbol]	= DRYER	[Symbol]	= ELECTRIC METER
[Symbol]	= ELECTRICAL PANEL	[Symbol]	= WALL HEATER
[Symbol]	= WATER HEATER	[Symbol]	= DATUM POINT
[Symbol]	= WATER SOFTNER	[Symbol]	= CEILING POINT
[Symbol]	= FLOOR DRAIN	[Symbol]	= HH = HEADER HEIGHT
[Symbol]	= GAS METER		

